

Suncoast

CUSTOM AMPLIFICATION



CUSTOM 18P GUITAR AMPLIFIER OWNERS MANUAL

**Copyright 2012, Sluggo Music Technology LLC
All Rights Reserved.**

Sluggo Music Limited Warranty

Sluggo Music Technology LLC warrants this product to be free of defects in material and workmanship for the period of one year from the date of original purchase. Vacuum tubes are warranted for 90 days from the date of purchase. This warranty is only applicable to the original retail purchaser. To be protected by this warranty, the purchaser must complete and return the enclosed warranty card within 14 days of the date of purchase. During the warranty period Sluggo Music shall, at its sole discretion, either repair or replace, free of charge, any product that it deems to be defective upon inspection by Sluggo Music Technology LLC or its **authorized service representative**. To obtain warranty service, the purchaser must first obtain a Return Authorization Number from our service department and shipping address where to return the unit for service. All authorized returns must be sent to our service department postage prepaid, insured for full replacement value, properly packaged and accompanied with a description of the problem. Sluggo Music reserves the right to update any unit returned for repair and the right to change or improve the design of the product at any time without prior notice. This warranty does not cover claims for damage due to abuse, neglect, alteration or attempted repair by unauthorized personnel, and is limited to failures arising during normal use that are due to defects in material or workmanship in the product only. Any warranties, including implied warranties of merchantability and fitness for a particular purpose, are limited in duration to the length of this original warranty. In no event will Sluggo Music Technology LLC be liable for incidental or consequential damages resulting from the breach of any express or implied warranty including damage to property, damage based on inconvenience or loss of use of the product, and personal injury to the extent permitted by law. This warranty gives you specific legal rights, which may vary from state to state. This warranty applies only to products sold in the United States of America. For warranty information in all other countries please refer to your local distributor.

Sluggo Music Technology LLC
P.O. Box 913
Dunedin, FL 34697-0913
(727) 247-2520

sales@sluggomusic.com
service@sluggomusic.com

**“SUNCOAST” is a trademark of
Sluggo Music Technology LLC, Copyright 2012
All Rights Reserved**

1 Overview

- 1.1 Introduction
- 1.2 Features

2 Controls

- 2.1 Front Panel Layout
- 2.2 Preamp Controls
- 2.3 Rear Panel Layout
- 2.4 Rear Panel Jack Description

3 Operation

- 3.1 Operating Instructions
- 3.2 External Effects Patching
- 3.3 Amplifier tone settings

4 Technical

- 4.1 Specifications
- 4.2 Vacuum Tube Replacement
- 4.3 Tube Location Diagram

1.1 Introduction

Thank you for purchasing the SUNCOAST CUSTOM 18P guitar amplifier. It is our commitment to providing our customers with the highest quality, handcrafted musical instrument amplifiers, built in the USA. Utilizing our knowledge of classic designs from the past 50 years, we set out to recreate that unique sound of some of our personal favorite artists. The Custom 18P is a low wattage amp whose design is based on the mid 70's HIWATT custom amplifiers. These amps were hand made for people like David Gilmour, Jimmy Page, and Pete Townsend and were the secret weapon for their distinctive tone. We first created a custom 20W, wide-bandwidth output transformer to emulate the response of the original Partridge transformer. Next, we re-designed the phase inverter circuit to drive the EL84 output stage for a bold, bright and aggressive tone of it's big brother. The footswitch now engages a treble boost in the last preamp stage for more Lead gain. Finally, we added a new balance control circuit to blend between the Normal and Brilliant input preamps. This new feature replaces having to jumper the two inputs together and adjust the levels separately. The ultimate British Tone amp at an 18W, club volume level.


1.2 Features

The following is a summary of your Custom 18P's unique features:

- Classic Mid 70's Preamp design.
- Custom 18W, Dual EL84 Output design.
- Custom Output and Power transformers.
- Front panel 18W/11W switch for Class AB Push-Pull or Single-Ended Class A output.
- Rear panel Pentode/Triode switch for Output tube operating mode.
- Rear panel effects loop Send and Return jacks.
- Rear panel line level Preamp Output jack.
- Separate 4, 8, 16 ohm speaker output jacks.
- Rear panel Standby switch.

*HIWATT is a trademark of their respective owners

2.1 Front Panel Layout



2.2 Preamp Controls

Hi & Lo Inputs - Hi and Lo gain instrument input jacks.

Footswitch Input – Footswitch input jack for Lead Treble Boost.

Balance – This control adjusts the blend between the Normal and Brilliant input preamps.

Volume – This control adjusts the input level of the preamp.

Bass – This tone control adjusts the amount of low frequencies.

Middle - This tone control adjusts the amount of midrange frequencies.

Treble - This tone control adjusts the amount of high frequencies.

Presence - This tone control adjusts the amount of upper high frequencies.

Master - This control adjusts the output level of the power amplifier.

18W/11W Mode Switch – Selects Class AB Push-Pull or Single-Ended Class A output power.

Indicator Lamp – Lights up red when power is On.

Power Switch – Main On/Off Switch.

2.3 Rear Panel Layout



2.4 Rear Panel Jack Description

Power Input - Power line cord input jack.

Main Fuse - Main power fuse. Replace with only same type and rating.

B+ Fuse - High Voltage tube power supply fuse.

Standby Power Switch - Unit standby power switch. Allowing the unit to warm up for one minute before turning the standby switch On will extend tube life.

Pentode/Triode Mode Switch - Power tube output mode select switch. Use the Pentode mode for that classic British rock tone. Triode mode has a darker tone with less edge suitable for Jazz and Blues.

4 Ohm Speaker Output Jack – Use this jack for a 4 Ohm speaker load.

8 Ohm Speaker Output Jack - Use this jack for a 8 Ohm speaker load.

16 Ohm Speaker Output Jack - Use this jack for a 16 Ohm speaker load.

Preamp Output Jack - Line level output to PA or slave power amp. This output is a line level attenuated signal taken from the 8 ohm speaker output.

Effects Return Jack - Input from external effects unit. This input is a pre master volume line level input.

Effects Send Jack - Output to external effects unit. This output is a post preamp line level output.

3.1 Operating Instructions

- Always connect the loudspeaker to the correct speaker output jack impedance prior to turning the unit ON.
- Use only correct 2-conductor speaker wire (16 gauge or greater) with mono ¼” ends. The use of coaxial instrument cable (guitar cord) for connecting speakers will invalidate your warranty and may damage your amplifier.
- Always connect the unit to the proper power source and use a grounded outlet, otherwise a shock hazard may result, especially when the unit is connected to other equipment. Domestic units should be connected to 115VAC, 60 Hz. Connection to improper line voltage will cause permanent damage.
- Do not expose this unit to rain or excessive moisture. This may cause a shock hazard or damage to the unit.
- Do not block the ventilation grilles on the rear panel of the amplifier head or top panel of the combo amp.
- Do not touch the output tubes while the unit is ON, severe burns can occur.

CAUTION: Use only one speaker output jack at a time. Using more than one jack at a time will overheat your output transformer.

WARNING: You MUST have a speaker load connected to this amp at all times. Operating the Custom 18P with no load will burn out your output tubes and could destroy the output transformer. This will void your warranty!

SAFETY NOTICE: Do not open the unit. There are no user serviceable parts inside the unit. Refer servicing to qualified personnel only. Extremely high voltages are present inside this unit that may result in severe injury or death.

3.2 External Effects Patching

Here is a list of effects in their respective order that can be used to achieve the ultimate British Tone. The rest of the magic is in your hands:

Guitar
|
Fuzz
Overdrive/Sustainer
Phase Shifter
Flanger
Tube Driver
Wah
Compressor
Chorus
|
Amplifier (HI Input)

Amplifier (Effects Send)
|
Volume Pedal
Digital Delay
Reverb/Echo
Noise Gate/Line Driver
|
Amplifier (Effects Return)

3.3 Amplifier Tone Settings

These settings are merely a suggested starting point from which you can set to your own personal taste.

Balance - 5
Volume - 6
Bass – 3
Middle – 4
Treble – 7
Presence – 7
Master – 5 (adjust for desired loudness)

4.1 Specifications

Input Line Voltage – 120VAC, 60Hz

Power Consumption – 55W

Line Fuse Rating – 1A, Time Lag

B+ Fuse Rating – 1/4A, Time Lag

Output Power – 18W RMS

Output Impedance – 4, 8, 16 Ohms

Tube Types: V1, V2, V4 – 12AX7 (ECC83)

V3 – 12AT7 (ECC81)

V5, V6 – 6BQ5 (EL84)

Dimensions: Amp Head – 20”W x 8.25”H x 8.25”D

Combo 1x12” – 24”W x 19.875”H x 9.5”D

Combo 2x12” – 28”W x 19.875”H x 10.5”D

Weight: Amp Head – 17lbs

Combo 1x12” – 35lbs

Combo 2x12” – 39lbs

4.2 Vacuum Tube Replacement

Generally speaking, tubes last a very long time. Output tubes should last for approximately 2000 hours or one year of daily use. Preamp tubes can last upwards of 15-30 years and do not need to be replaced unless they become noisy with popping or microphonic squeals through your speakers. Your amp comes stock with JJ - 12AX7 preamp tubes and a matched pair of Mullard EL84 output tubes. The phase inverter tube (V3) is a JJ - 12AT7, low gain tube. Using a different type of tube other than a 12AT7 for V3 can result in high frequency oscillations. We do not recommend any substitutes. **ALWAYS** disconnect the power to the unit and let the tubes cool before replacement.

4.3 Tube Location Diagram

